


Module Interface



* Nicht in Europa erhältlich
 * Not available in Europe
 * Non disponible en Europe

Interface Features

1	IC-J LED	Type J TC indicator
2	CA-K LED	Type K TC indicator
3	SOFT LED	Indicates module in Soft Start phase
4	OUT LED	Indicates power output from module
5	PV Display	Displays Present Value (PV) of measured temperature (red four digit display)
6	SV Display	Displays Set Value (SV) for temperature (green four digit display)
7	AUTO LED	Indicates module in Automatic Operation
8	MAN/BST LED	Blink - Indicates module in Manual Operation ON - Indicates module utilizing Boost feature
9	STANDBY LED	Indicates module utilizing Standby feature
10	▲	Value increase button
11	▼	Value decrease button
12	MODE	MODE button
13	SET	SET button
14	SEL	SEL button
15	Handle	
16	On/Off Switch	
17	Lock Pin	