




**Abstand Basisstecker für 1614-BPA und 4814-BPA**  
Base Plug Clearance for 1614-BPA & 4814-BPA  
Dégagement pour prise à la base pour 1614-BPA & 4814-BPA




MONTAGEABMESSUNGEN  
MOUNTING DIMENSIONS  
DIMENSIONS DU SUPPORT



DIMENSIONS	1614-BPA	4814-BPA
A	4.100	5.800
B	2.050	2.900
C	3.465	4.325
D	1.733	2.163
E	2.400	3.500
F	4.800	7.000
G	0.725	1.470
H	1.450	2.940
J	0.825	1.375
K	1.250	2.750
L	0.875	2.400
M	4.160	7.600
N	2.000	2.500

**Abstand Basisstecker für 3214-BPA**  
Base Plug Clearance for 3214-BPA  
Dégagement pour prise à la base pour 3214-BPA

MONTAGEABMESSUNGEN  
MOUNTING DIMENSIONS  
DIMENSIONS DU SUPPORT



**Abstand Basisstecker für 32 M-BPA**  
Base Plug Clearance for 32 M-BPA  
Dégagement pour prise à la base pour 32 M-BPA

MONTAGEABMESSUNGEN  
MOUNTING DIMENSIONS  
DIMENSIONS DU SUPPORT

